

Black Powdercoat Steel Stand and Shelves Installation Guide

Tools Required

- Drill
- Screwdriver
- Level
- Pencil
- Stud Finder



1.



Unbox console sink stand and lay out each piece. There should be two sets of legs, two shelves, a straight bar, as well as a small bag of hardware. Set the hardware to the side.

2.



Lay one set of legs on the ground so that the brackets face up. Take the shelf and insert the brackets into the holes on the side of the shelf. Make sure the screw holes are lined up. Repeat this process for the other shelf.

3.



Once both shelves are inserted onto the legs, attach the straight bar to the remaining brackets at the top.

4.



Take the remaining set of legs and carefully insert the brackets into the shelves and bar. Up to this point, no hardware has been used.

5.



Flip the stand so that the legs are in the air and the straight bar is on the ground. Screw the leveling feet into the legs of the stand. These can be adjusted to ensure a level sink.

6.



Screw the short silver screws into the shelves on the underside. There are eight screws per shelf and four for the bar at the top.

7.



Locate the place where the sink will be installed. Use a pencil to identify where the mounting holes line up with the wall. This is when the adjusting feet should be made level.

8.



Use a stud finder to locate studs to fasten the stand to the wall. If studs do not line up with the mounting location of the stand, wood blocking can be installed between the studs using standard 2x4's.

9.



Drill pilot holes into the wall.

10.



Lightly push the wall anchors into the holes so they will not fall out, then place the stand where it is about to go. Before you drill, make sure the cap washers are on the long black screws. Then drill them into place.

11.



Finally, press the black caps overtop the screws.