



Shower Panel Instructions

Unpack your shower panel and inspect it for any damage.

(If you have any concerns please contact Magnus Home Products toll free number 833-482-6828)

Adhere to your plumbing and building codes that provide regulations and a set of laws for inspection and installation to where the bottom bracket will be installed. Not all panels will have (2) brackets.

*Basic handtools required.

Installation Instructions

1. Attach the bracket to the wall.
2. Connect and secure the hot and cold flexible hoses.
3. Turn off the cold and hot water supplies to the location of the installation.
4. Hold up the shower panel to determine the height that will be suitable for all individuals using the product.
5. Mark the area where the top bracket will be installed.
6. Measure down from the height of the top bracket hoses to the water lines out of the wall.
7. Slide the shower panel down so it rests on the mounting brackets. Pull down onto the brackets until the panel stops moving.
8. Check for any water leaks.
9. Seal the shower panel with a neutral cure silicone to the bottom and sides where the panel is in contact with the wall.