



## **Corner Basin Sink Installation Instructions**

---

### **Tools Needed:**

- Screwdriver
- Drill & Bits
- Level
- Plumbers Basin Wrench to secure Faucet (Optional)
- Wrench
- Pencil

\*\*mounting hardware included

### **Installation Instructions:**

1. Determine the height you want. Place sink in the corner. Use a level to make sure both sides are level.
2. Install mounting studs in the proper locations on the wall. Mark the location of mounting bracket holes on the wall.
3. Remove the bowl from the wall.
4. Start to drill hole through 2"x12" re-inforced wall for the mounting hardware. If drill bit hits a stud, mount studs using mounting hardware.
5. Before replacing bowl, it would be convenient at this point to mount the faucet according to the manufacturer's instructions.
6. Hang bowl on mounting studs and ensure that it is level.
7. Connect all supply tubes to the faucet. Connect trap and drain assembly as described by the manufacturer.

*\*Be sure to re-inforce wall before installation. We recommend a 2"x12" securely fastened to wall studs at desired height for installation.*