



## **Shower Rod Installation**

---

### **Tools Needed:**

- Small Blade Screwdriver
- Phillips Screwdriver
- Level
- Drill with 1/8" Bit
- Pipe Cutter / Hacksaw (Optional)

### **Parts Included:**

- 2 Straight Rods
- 2 Flanges
- Mounting Hardware



## **Installation Instructions**

1. Measure wall opening.
2. Place the two ends of the rod together, if it came as two pieces.
3. Measure rod. You can cut both ends to shorten rod. You can increase size by sliding flange out up to 1/2" (1" total). For best results, have rods extend into flange up to the end of the guides inside the flange.
4. When desired size is achieved, slide flanges on each end and install rod in opening.  
\*\* Do Not use set screws yet. \*\*
5. After rod is secured to walls, use a level to make sure rod is level side to side and front to back. Now install set screws. A 1/8" pilot hole is recommended for optimum strength.