

## Installation instructions

### - Freestanding Tub Faucet Manual

CAREFULLY READ THIS INSTRUCTION MANUAL BEFORE INSTALLING AND USING THIS PRODUCT


PLEASE KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE FOR PRODUCT OPERATION AND MAINTENANCE








#### BEFORE BEGINNING INSTALLATION


1. Flush plumbing lines to clear any debris.
2. Shut off both supply lines after flushing.

#### Tools Required:




#### Parts:


Screw	Cone Washer & Coupling Nut	Base Plate & Sleeve & Sleeve Extension	Adapter	Screw & Anchor
				
3 Pcs	2 Pcs	1 Pc	2 Pcs	8 Pcs




Prepare location by securing a platform 2 5/8" below the finish surface of the floor. If you are building on a concrete slab, you may have to build a platform above ground. Secure the base with three of the included screws.




Thread base plate, feed faucet supply lines through the base sleeve extension and insert into body of faucet. Thread base sleeve to sleeve extension, secure faucet assembly by inserting into base plate and twisting in a clockwise direction until it is locked into place. Make sure the faucet supply lines are protruding from base sleeve prior to securing the base plate.




Apply Teflon tape to the hose fitting threads, and thread the adapters to the inlet hose fittings, do not over-tighten as this may result in damage and leaking.




Secure faucet assembly by inserting into base plate and twisting in a clockwise direction until it is locked into place.




Using the proper anchors, secure the faucet to the floor by threading all 8 screws on the baseplate. For wooden floors, it may be necessary to reinforce the floor underneath by adding a 2"x4" piece of lumber for the screws to support the faucet.



Slide flange down to cover the base plate. Depending on field conditions, in some cases it may be easier to connect the supply lines prior to securing the faucet.



Apply Teflon tape to the adapter threads, while holding the adaptor securely with a wrench, thread supply lines, do not allow adaptor to turn as this may cause damage and leaking.



Attach hose to hand shower outlet and turn on faucet, let water flow out of spout for at least 1 minute alternating between hot and cold water. Turn diverter to hand shower by turning knob located under the spout and let water run for 1 minute, replace aerator and attach hand shower to hose.

### WARNING!!!

- Do not over-tighten nut during installation.
- Over-tighten may crack the valve and cause severe leak.